



The unblock procedure for the Iridium SIM card is:

On the Iridium phone, enter

****05***

Enter 8-digit code (PUK #), then press OK

Enter 1111 (default PIN), then press OK

Enter 1111 again, then press OK

Should then say COMPLETED and phone should now be unblocked

To disable the PIN feature for Iridium models 9500, 9505 and 9505A:

You press the MENU button consecutively until "Phone Setup" and then press OK

You press the MENU button consecutively until "PIN required" and press OK

You press the arrow keys to OFF and press OK

You enter the PIN, 1111 and press OK.

You can also change the menu in French if you continue to press the MENU consecutively until "language" and press OK

You press the arrows to French and press OK

To disable the PIN feature for Iridium models 9555 and 9575:

From the Main Menu:

Use the **2-way Navi-key** to scroll until **Security** is highlighted.

Note: Scroll one down from **Setup** to view the **Security** option.

Press the **left soft key**, labeled **Select**.

Use the **2-way Navi-key** to scroll until **SIM lock** is highlighted.

Press the **left soft key**, labelled **Select**.

Use the **2-way Navi-key** until the action you prefer is highlighted.

The **Enter PIN** screen appears. Using the keypad enter **1111**.

Press the **left soft key**, labelled **Select**.

The message **SIM lock disabled** briefly appears, then returns to the SIM Lock menu.